

# ECG EDF 6066 QXD

## Dishwasher

Product code: 100000841199
EAN: 8592131239715

- Energy efficiency class: D
- 6 programs
- 14 sets of plates
- Water consumption: 10 l




- Freestanding dishwasher
- 60 cm width
- 14 dish sets
- 6 programmes:
  - Intensive: for heavily soiled pots and pans and dishes with dried food remains
  - ECO: for normally soiled loads, such as pots, plates, glasses and lightly dirty pans
  - Light: light washing program is suitable for delicate dishes, sensitive to high temperatures
  - 60 min: lightly and normally soiled glasses, plates or bowls, everyday washing
  - Fast: quick programme for lightly soiled dishes that do not need to be dried
  - Rinse: to rinse dishes, which you want to wash later
- Energy Class D
- Delay start
- Dual zone wash ( half loading)
- LED display
- Adjustable height of upper basket
- Special drawer compartment for utensils
- ECO programme
- 3in1 tablets
- Aquastop
- Noise level: 46 dB
- Water consumption: 10 l
- Dimensions (H x W x D): 84.5 x 60 x 60 cm
- Power input: 1850 W
- Rated voltage/frequency: 220–240 Vac / 50 Hz

## Technical specifications

| | |
|---|---|
| Rated capacity - number of sets | 14 |
| EEI | 49.9 |
| Energy efficiency class | D |
| Cleaning ability index | 1.13 |
| Drying ability index | 1.09 |
| Energy consumption per 100 cycles (kWh) | 84 |
| Weighed water consumption per cycle (l) | 10 |
| Length of reference program (hrs.) | 3.59 |
| Noise (dB) | 46 |
| Noise emission class | C |
| Turned off (W) | 0.49 |
| Standby mode (W) | 0.6 |
| Delayed start (W) | 1 |
| Standby mode when connected to power (W) | - |
| Automatic detergent dispensing | - |
| Program for 3in1 tablets | Yes |
| Motor type | normal |
| Wifi connection | no |
| Power cable length (cm) | 150 |

## Control

| | |
|---|---|
| Number of washing temperatures | 4 |
| Temperatures | 45/48/50/60 |
| Recommended water pressure | 0,04-1,00 Mpa |
| Self-cleaning function | no |
| Automatic self-cleaning reminder | no |
| Self-cleaning stainless steel filter | no |
| Half load half load | Yes |
| Interior surface | Stainless |
| Fingerprint protection | Yes |

## Bakets

| | |
|---|---|
| Baskets color | grey |
| Glasses module in the upper / lower basket | no |
| Height adjustable upper basket | Yes |
| Setting of the upper loaded basket | Yes |
| basket handle | Yes |
| basket handle with logo | Yes |
| Cutlery basket | no |
| Extra cutlery compartment | Yes |

## Products specifications

| | |
|---|---|
| Lower spray arm | Plastic |
| Upper spray arm | Plastic |

| | |
|---|---|
| Upper spray | Yes |
| Rotating upper spray | Yes |
| Number of washing arms | 2 |
| Filter | Stainless |
| Water softener | Yes |
| Water softener control | electronic |
| Rinse control | electronic |
| Supply hose material | rubber |
| Supply hose length | 150 |
| Aquastop system (exterior base) | Yes |
| Drain hose | Yes |
| Drain hose length | 160 |
| Supply and drain hoses in the package | Yes |
| Water relief valve (DualZone) | no |
| Heating element | concealed |
| Water sensor / overflow | Yes |
| Water source | hot/cold |
| Power | 220-240V 50Hz |
| Steam protection | no |
| Outlet | Euro schuko |
| Quantitative automation | no |
| Load sensor | no |
| Aquastop hose | Yes |
| Automatic door opening | no |
| Water tank | no |
| XXL (86 cm) Version | no |
| Status light indicator | no |
| Interior lighting | no |
| Steam disinfection | no |
| Ion generator | no |
| Self-cleaning program | no |
| Start / Pause button | Yes |
| Program selection button | Yes |
| Half-load button | no |
| Quick rinse button | no |
| Extra hygiene button | no |
| Extra drying button | no |
| Child lock | Yes |
| Automatic door opening button | no |
| Optical signal of program end | no |
| Audible signal of program end | Yes |

## Design

| | |
|---|---|
| Material | - |
| Color design of the dishwasher | Stainless |
| Control panel type | Plastic |
| Control panel color | Silver |

| | |
|---|---|
| Control panel insert | Silver |
| Buttons color | Silver |
| Sliding door | no |
| Hinges | Yes |
| Spring control | Yes |
| Adjustable front spring opening | Yes |
| Adjustable feet | Yes |
| Height adjustable (in mm) | 50 |
| Adjustment of rear feet from the front | Yes |
| Sheet metal on sides | Yes |
| Top plate | Yes |
| Rear plate | no |

## Control

| | |
|---|---|
| Audible alert at the end of washing | Yes |
| Possibility to turn off / on the sound alert of the end of the program | no |
| Operation indicator | Yes |
| Washing phase indicator | no |
| Lack of salt indicator | no |
| Lack of polish indicator | no |
| Delayed start (hrs) | 1-24 |
| Gentle washing of glass function | no |
| Time control | no |
| Clock | Yes |

## Programs

| | |
|---|---|
| Number of programs | 6 |
| Auto program | no |
| Special programs | no |

## Weight & dimensions

| | |
|---|---|
| WIDTH (MM) | 600 |
| HEIGHT (MM) | 845 |
| LENGTH (MM) | 600 |
| WEIGHT (KG) | 47.0 |

## Weight & dimensions (Brutto)

| | |
|---|---|
| WIDTH WITH PACKAGING (MM) | 640 |
| HEIGHT WITH PACKAGING (MM) | 875 |
| DEPTH WITH PACKAGING (MM) | 640 |
| WEIGHT WITH PACKAGING (KG) | 50.0 |

## Powerful and economical at the same time



The **ECG EDF 6066 QXD** free standing dishwasher belongs among the class of dishwashers with standard width of 60 cm. This model is ready to wash up to **14 dining sets**, which is very convenient for family celebrations or other large events.

Its water consumption is not high. It needs **10 litres** to wash your dishes. Thanks to energy class D, it is one of the most economical appliances, which you will definitely appreciate when paying for electricity.

## Varied selection of programs



The dishwasher offers **6 programs**, which will certainly cover all the needs of perfect washing of your dishes. For example, the Intensive program gets rid of dried food residues, Light washing program is suitable for more delicate dishes, sensitive to high temperatures. The Quick program is used for lightly soiled dishes that do not need to be dried. You can also use Eco, 60 minutes and Rinse.

## Sophisticated drawers



The ECG EDF 6066 QXD dishwasher has very sophisticated drawers. The **cutlery drawer** is telescopically adjustable. The back of the bottom drawer has folding pins. In the upper drawer, these folding pins are even in the entire drawer. There are also two removable ½ holders for glasses, cups or wine glasses located on the left. **Easy Fold Function** allows easy adjustment of the height of the filled upper basket.

## Set start



Don't want to turn on the dishwasher right now, but need to move the wash up to a more convenient time? That’s no problem. The **Delayed start function** will take care of that. With it, you can plan to turn on the dishwasher up to 24 hours later, even during your absence from the apartment. The dishwasher is equipped with a special flooding protection system. The **Aquastop function** ensures that the water supply to the appliance automatically stops in the event of a malfunction or flooding.

## Carefree dishwashing



Operating the dishwasher is very simple. A clear **LED display** where you can see all you need will help you with your choice. It is not always possible to accumulate enough dishes to fill the entire dishwasher. **Dual zone wash** (half load) is an additional function of the dishwasher, which allows a full wash for half the amount of dishes.

Whether you have a completely or only partially filled dishwasher, two washing arms and an overhead rotary shower will ensure perfectly clean dishes. This model also uses a water softener or a 3-in-1 tablet function. In addition, it has a child lock, so you can be sure that the dishwasher is safe from your children and vice versa.