



# ECG EDF 6066 QXD

## Dishwasher

Product code: 100000841199

EAN: 8592131239715

- Energy efficiency class: D
- 6 programs
- 14 sets of plates
- Water consumption: 10 l



- Freestanding dishwasher

- 60 cm width

- 14 dish sets

- 6 programmes:

- Intensive: for heavily soiled pots and pans and dishes with dried food remains
- ECO: for normally soiled loads, such as pots, plates, glasses and lightly dirty pans
- Light: light washing program is suitable for delicate dishes, sensitive to high temperatures

- 60 min: lightly and normally soiled glasses, plates or bowls, everyday washing

- Fast: quick programme for lightly soiled dishes that do not need to be dried

- Rinse: to rinse dishes, which you want to wash later

- Energy Class D

- Delay start

- Dual zone wash ( half loading)

- LED display

- Adjustable height of upper basket

- Special drawer compartment for utensils

- ECO programme

- 3in1 tablets

- Aquastop

- Noise level: 46 dB

- Water consumption: 10 l

- Dimensions (H x W x D): 84.5 x 60 x 60 cm

- Power input: 1850 W

- Rated voltage/frequency: 220–240 Vac / 50 Hz

## Technical specifications

Rated capacity - number of sets	14
EEl	49.9
Energy efficiency class	D
Cleaning ability index	1.13
Drying ability index	1.09
Energy consumption per 100 cycles (kWh)	84
Weighed water consumption per cycle (l)	10
Length of reference program (hrs.)	3.59
Noise (dB)	46
Noise emission class	C
Turned off (W)	0.49
Standby mode (W)	0.6
Delayed start (W)	1
Standby mode when connected to power (W)	-
Automatic detergent dispensing	-
Program for 3in1 tablets	Yes
Motor type	normal
Wifi connection	no
Power cable length (cm)	150

## Control

Number of washing temperatures	4
Temperatures	45/48/50/60
Recommended water pressure	0,04-1,00 Mpa
Self-cleaning function	no
Automatic self-cleaning reminder	no
Self-cleaning stainless steel filter	no
Half load half load	Yes
Interior surface	Stainless
Fingerprint protection	Yes

## Baskets

Baskets color	grey
Glasses module in the upper / lower basket	no

Height adjustable upper basket	Yes
Setting of the upper loaded basket	Yes
basket handle	Yes
basket handle with logo	Yes
Cutlery basket	no
Extra cutlery compartment	Yes

## Products specifications

Lower spray arm	Plastic
Upper spray arm	Plastic
Upper spray	Yes
Rotating upper spray	Yes
Number of washing arms	2
Filter	Stainless
Water softener	Yes
Water softener control	electronic
Rinse control	electronic
Supply hose material	rubber
Supply hose length	150
Aquastop system (exterior base)	Yes
Drain hose	Yes
Drain hose length	160
Supply and drain hoses in the package	Yes
Water relief valve (DualZone)	no
Heating element	concealed
Water sensor / overflow	Yes
Water source	hot/cold
Power	220-240V 50Hz
Steam protection	no
Outlet	Euro schuko
Quantitative automation	no
Load sensor	no
Aquastop hose	Yes
Automatic door opening	no
Water tank	no
XXL (86 cm) Version	no
Status light indicator	no
Interior lighting	no
Steam disinfection	no

Ion generator	no
Self-cleaning program	no
Start / Pause button	Yes
Program selection button	Yes
Half-load button	no
Quick rinse button	no
Extra hygiene button	no
Extra drying button	no
Child lock	Yes
Automatic door opening button	no
Optical signal of program end	no
Audible signal of program end	Yes

## Design

Material	-
Color design of the dishwasher	Stainless
Control panel type	Plastic
Control panel color	Silver
Control panel insert	Silver
Buttons color	Silver
Sliding door	no
Hinges	Yes
Spring control	Yes
Adjustable front spring opening	Yes
Adjustable feet	Yes
Height adjustable (in mm)	50
Adjustment of rear feet from the front	Yes
Sheet metal on sides	Yes
Top plate	Yes
Rear plate	no

## Control

Audible alert at the end of washing	Yes
Possibility to turn off / on the sound alert of the end of the program	no
Operation indicator	Yes
Washing phase indicator	no
Lack of salt indicator	no
Lack of polish indicator	no

Delayed start (hrs)	1-24
Gentle washing of glass function	no
Time control	no
Clock	Yes

## Programs

---

Number of programs	6
Auto program	no
Special programs	no

## Weight & dimensions

---

WIDTH (MM)	600
HEIGHT (MM)	845
LENGTH (MM)	600
WEIGHT (KG)	47.0

## Weight & dimensions

---

### (Brutto)

WIDTH WITH PACKAGING (MM)	640
HEIGHT WITH PACKAGING (MM)	875
DEPTH WITH PACKAGING (MM)	640
WEIGHT WITH PACKAGING (KG)	50.0

## Powerful and economical at the same time

The **ECG EDF 6066 QXD** free standing dishwasher belongs among the class of dishwashers with standard width of 60 cm. This model is ready to wash up to **14 dining sets**, which is very convenient for family celebrations or other large events.

Its water consumption is not high. It needs **10 litres** to wash your dishes. Thanks to energy class D, it is one of the most economical appliances, which you will definitely appreciate when paying for electricity.




## Varied selection of programs

The dishwasher offers **6 programs**, which will certainly cover all the needs of perfect washing of your dishes. For example, the Intensive program gets rid of dried food residues, Light washing program is suitable for more delicate dishes, sensitive to high temperatures. The Quick program is used for lightly soiled dishes that do not need to be dried. You can also use Eco, 60 minutes and Rinse.



## Sophisticated drawers

The ECG EDF 6066 QXD dishwasher has very sophisticated drawers. The **cutlery drawer** is telescopically adjustable. The back of the bottom drawer has folding pins. In the upper drawer, these folding pins are even in the entire drawer. There are also two removable  $\frac{1}{2}$  holders for glasses, cups or wine glasses located on the left. **Easy Fold Function** allows easy adjustment of the height of the filled upper basket.



## Set start

Don't want to turn on the dishwasher right now, but need to move the wash up to a more convenient time? That's no problem. The **Delayed start function** will take care of that. With it, you can plan to turn on the dishwasher up to 24 hours later, even during your absence from the apartment. The dishwasher is equipped with a special flooding protection system. The **Aquastop function** ensures that the water supply to the appliance automatically stops in the event of a malfunction or flooding.



## Carefree dishwashing

Operating the dishwasher is very simple. A clear **LED display** where you can see all you need will help you with your choice. It is not always possible to accumulate enough dishes to fill the entire dishwasher. **Dual zone wash** (half load) is an additional function of the dishwasher, which allows a full wash for half the amount of dishes.



Whether you have a completely or only partially filled dishwasher, two washing arms and an overhead rotary shower will ensure perfectly clean dishes. This model also uses a water softener or a 3-in-1 tablet function. In addition, it has a child lock, so you can be sure that the dishwasher is safe from your children and vice versa.