



# **ECG AF 4000 Simply Fry**

## Hot air fryer

Product code: 100002129688

EAN: 8592131000650

- Healthier preparation of baked, baked and fried dishes
- Modern technology consisting in 3D circulation of hot air
- The possibility of preparing food for the whole family thanks to the large capacity of 3.8 I
- Timer and continuously adjustable temperature
- Non-stick surface for easier maintenance

- Healthier preparation of your favorite baked, baked or fried dishes (with a minimum amount of oil) using hot air
- The ideal choice for preparing fries, meat, vegetables, but also desserts and other dishes
- Large capacity of 3.8 l, thanks to which you can prepare food for the whole family in the deep fryer
- Removable container
- Non-stick surface that prevents food from sticking and makes maintenance easier

- Quick and efficient cooking thanks to 3D hot air circulation and 1300 W
- Possibility of continuously adjusting the temperature in a wide range of 80-200
- A timer that automatically turns off the device after the set time has elapsed
- Sound and light signaling for maximum safety and user comfort (the device informs you about its operation, temperature and end of frying)
- Intuitive control, through which you can easily choose the temperature and preparation time

- Temperature-insulated handle that won't burn you
- Anti-slip mats that keep the fryer firmly in place
- Automatic shutdown after frying
- Modern design with black-silver finish
- Compact design with dimensions of 32.8 x 31.7 x 25 cm
- Weight 3.5 kg
- Connection to a classic socket (voltage 220-240 V; 50/60 Hz)
- Length of the supply cable 75 cm



## **Technical specifications**

Input power (W)	1300
Voltage/Frequency (V/Hz)	220-240 ~ 50/60
Heat isolated handle	Yes

### **Product specifications**

Temperature range         80-200°C           Variable temperature         Yes           Temperature control         Yes           3D heating         Yes           Blice cooker         No           Pilaf         No           Baking         Yes           Jam         No           Boil         No           Stewing         No           Stewing         No           Stewing         No           Stewn         No           Stewn         No           Sow cooking         No           Intuitive display         No           Control mode         manual buttons           Maintaining the temperature after cooking         No           Bound indicator         Yes           Power light indicator         Yes           Removable bowl         No-stick           Bowl surface         No-stick           Removable power cord         No           Removable power cord         No	Container capacity (I)	4
Temperature control         Yes           3D heating         Yes           Rice cooker         No           Pilaf         No           Baking         Yes           Jam         No           Boil         No           Stewing         No           Stewing         No           Frying         Yes           Warm         No           Slow cooking         No           Inutive display         No           Delayed start         No           Control mode         manual buttons           Maintaining the temperature after cooking         No           Digital Timer Setting         No           Sown oli Indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stip           Itansparent lid         No           Non-slip feet         Yes	Temperature range	80-200°C
3D heating         Yes           Rice cooker         No           Pilaf         No           Baking         Yes           Jam         No           Boil         No           Stewing         No           Steam         No           Frying         Yes           Warm         No           Slow cooking         No           Intuitive display         No           Delayed start         No           Control mode         manual buttors           Maintaining the temperature after cooking         No           Sound indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stip           Transparent lid         No           Non-slip feet         Yes	Variable temperature	Yes
Rice cooker         No           Pilaf         No           Baking         Yes           Jam         No           Boil         No           Stewing         No           Steam         No           Frying         Yes           Warm         No           Slow cooking         No           Intuitive display         No           Delayed start         No           Control mode         manual buttons           Maintaining the temperature after cooking         No           Sound indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stick           Transparent lid         No           Non-slip feet         Yes	Temperature control	Yes
Plaif         No           Baking         Yes           Jam         No           Boil         No           Stewing         No           Steam         No           Frying         Yes           Warm         No           Slow cooking         No           Intuitive display         No           Delayed start         No           Control mode         manual button           Maintaining the temperature after cooking         No           Digital Timer Setting         No           Sound indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stick           Transparent lid         No           Non-slip feet         Yes	3D heating	Yes
Baking         Yes           Jam         No           Boil         No           Stewing         No           Steam         No           Frying         Yes           Warm         No           Slow cooking         No           Intuitive display         No           Delayed start         No           Control mode         manual buttons           Maintaining the temperature after cooking         No           Digital Timer Setting         No           Sound indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stick           Transparent lid         No           Nor-slip feet         Yes	Rice cooker	No
Jam         No           Boil         No           Stewing         No           Steam         No           Frying         Yes           Warm         No           Slow cooking         No           Intuitive display         No           Delayed start         No           Control mode         manual buttons           Maintaining the temperature after cooking         No           Digital Timer Setting         No           Sound indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stick           Transparent lid         No           Non-slip feet         Yes	Pilaf	No
Boil         No           Stewing         No           Steam         No           Frying         Yes           Warm         No           Slow cooking         No           Intuitive display         No           Delayed start         No           Control mode         manual buttons           Maintaining the temperature after cooking         No           Digital Timer Setting         No           Sound indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stick           Transparent lid         No           Non-slip feet         Yes	Baking	Yes
Stewing         No           Steam         No           Frying         Yes           Warm         No           Slow cooking         No           Intuitive display         No           Delayed start         No           Control mode         manual buttons           Maintaining the temperature after cooking         No           Digital Timer Setting         No           Sound indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stick           Transparent lid         No           Non-slip feet         Yes	Jam	No
Steam         No           Frying         Yes           Warm         No           Slow cooking         No           Intuitive display         No           Delayed start         No           Control mode         manual buttons           Maintaining the temperature after cooking         No           Digital Timer Setting         No           Sound indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stick           Transparent lid         No           Non-slip feet         Yes	Boil	No
Frying         Yes           Warm         No           Slow cooking         No           Intuitive display         No           Delayed start         No           Control mode         manual buttons           Maintaining the temperature after cooking         No           Digital Timer Setting         No           Sound indicator         Yes           Power light indicator         Yes           Removable bowl         Yes           Bowl surface         Non-stick           Transparent lid         No           Non-slip feet         Yes	Stewing	No
WarmNoSlow cookingNoIntuitive displayNoDelayed startNoControl modemanual buttonsMaintaining the temperature after cookingNoDigital Timer SettingNoSound indicatorYesPower light indicatorYesRemovable bowlYesBowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Steam	No
Slow cookingNoIntuitive displayNoDelayed startNoControl modemanual buttonsMaintaining the temperature after cookingNoDigital Timer SettingNoSound indicatorYesPower light indicatorYesRemovable bowlYesBowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Frying	Yes
Intuitive display  Delayed start  Control mode  Maintaining the temperature after cooking  Digital Timer Setting  Sound indicator  Fower light indicator  Removable bowl  Bowl surface  Transparent lid  Non-stick  Non-slip feet	Warm	No
Delayed startNoControl modemanual buttonsMaintaining the temperature after cookingNoDigital Timer SettingNoSound indicatorYesPower light indicatorYesRemovable bowlYesBowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Slow cooking	No
Control modemanual buttonsMaintaining the temperature after cookingNoDigital Timer SettingNoSound indicatorYesPower light indicatorYesRemovable bowlYesBowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Intuitive display	No
Maintaining the temperature after cookingNoDigital Timer SettingNoSound indicatorYesPower light indicatorYesRemovable bowlYesBowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Delayed start	No
Digital Timer SettingNoSound indicatorYesPower light indicatorYesRemovable bowlYesBowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Control mode	manual buttons
Sound indicatorYesPower light indicatorYesRemovable bowlYesBowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Maintaining the temperature after cooking	No
Power light indicatorYesRemovable bowlYesBowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Digital Timer Setting	No
Removable bowlYesBowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Sound indicator	Yes
Bowl surfaceNon-stickTransparent lidNoNon-slip feetYes	Power light indicator	Yes
Transparent lid No Non-slip feet Yes	Removable bowl	Yes
Non-slip feet Yes	Bowl surface	Non-stick
	Transparent lid	No
Removable power cord No	Non-slip feet	Yes
	Removable power cord	No

#### Design

Colour	Black/Silver
Material	Plastic/Glass

#### **Accessories**

Stirring paddle	No
Spatula	No
Grilling grid	No
Fry basket	Yes
Steamer	No
Measure cup	No



Scoop/Ladle	No
Ladle holder	No
Weight & dimensions	
WIDTH (MM)	245
HEIGHT (MM)	300
LENGTH (MM)	290
WEIGHT (KG)	3.2
Weight & dimensions (Brutto)	
WIDTH WITH PACKAGING (MM)	295
HEIGHT WITH PACKAGING (MM)	295
DEPTH WITH PACKAGING (MM)	335
WEIGHT WITH PACKAGING (KG)	3.5



#### Healthy cooking without compromises

Treat yourself to delicious and perfectly crispy dishes without unnecessary fat. The hot air fryer ECG AF 4000 Simply Fry works on the principle of 3D circulation of hot air, and thus allows you to prepare food with a minimum amount of oil - in short, healthy, tasty and modern. You can look forward to fries, chicken wings, vegetables and irresistible desserts. The device is capable of frying, baking and baking - you can do all this in one single appliance and without unnecessarily used fat, which you would have to complain about.



#### Ideal capacity for the whole family

With the volume of the removable frying basket **3.8 liters**, you can prepare enough food for the whole family or a small celebration with friends. The great news is also the **non-stick surface**, thanks to which the food does not stick and the maintenance of the fryer is extremely simple.



#### Easy and intuitive operation

Simple manual control allows you to set the frying time and choose exactly the temperature required by the dish - you have a range from 80 °C to 200 °C. At the same time, you are in control of the frying process via light and sound signaling. The device informs you about its operation and temperature and also informs you in time that frying is over.



#### Safety always comes first

The ECG AF 4000 Simply Fry hot air fryer includes a **thermally insulated handle**, which is safe to touch even during operation. **Non-slip mats** in turn ensure the stability of the appliance and minimize the risk of tipping over on the work surface. And of course there is also **automatic shutdown**. The fryer works with **1300 W** power and is connected **to a classic socket**. The length of the supply cable is **75 cm** sufficient.



#### A compact, stylish and reliable helper

Compact design with dimensions 32.8 x 31.7 x 25 cm and timeless design with black-silver finish. These are the features that make this hot air fryer an appliance that simply cannot be resisted. It will not take up too much space in your kitchen, and thanks to its elegant appearance, it will fit perfectly among other appliances and into any interior. However, the most important thing is of course its reliability and great functionality - whether you are preparing traditional fries, crispy meat, roasted vegetables or muffins, it will allow you to cook tasty, fast, healthy and without unnecessary effort.

